

## HOW TO Install the Mosquito Magnum+ on Voron Stealthburner

Difficulty **Easy**  
Steps **5**  
Time Required **5 to 10 min**  
Sections **1**



PRODUCT PAGE



## INSTRUCTIONS GUIDE

This guide is designed to be a reference manual for the installation of a Mosquito Magnum+ on the Voron Stealthburner platform. Follow the instructions below or, if you prefer to watch a YouTube video with the same instructions, use the provided link below or the YouTube icon to the right:

<https://youtu.be/WqN-3XO5fuo>



01 Add Magnum+ to the hotend mount



02 Insert the two M2.5x10 SHCS screws and tighten them



03 Place the hotend mount rear piece on the assembly



04 Add and tighten the two M3x16 SHCS screws



05 Add the hotend to your x-carriage, insert PTFE and connect wires according to your specific setup

### **IT'S DONE! TAKE GOOD CARE OF IT**

Make sure you take part of the safety warnings and surrounding documents for the Magnum+

*<https://support.sliceengineering.com/>*

### **HOW TO GET HELP**

We are available to help you with any questions or issues you may have. Simply go to our website where you can access our customer support and send us your questions or follow the provided link:

*[https://www.bondtech.se/contact/#tab\\_technical-support-requests](https://www.bondtech.se/contact/#tab_technical-support-requests)*

