ноw то Install an EBB36 mount on Voron Stealthburner

Difficulty *Medium*

Steps 13

Time Required 10 to 15 min

Sections 1







INSTRUCTIONS GUIDE

This guide is designed to be a reference manual for the installation of an EBB36 mount on the Voron Stealthburner platform. Follow the instructions below or, if you prefer to watch a YouTube video with the same instructions, use the provided link below or the YouTube icon to the right:

https://youtu.be/mTPb8EO6j_M





Take the EBB36 and add two M3x8 SHCS



Add the two spacers fitting your extruder variation and screw the EBB36 to the mount



Remove the lower nut from the PG7 and screw it into the mount



Add the EBB36 assembly to the extruder assembly



Add 2x M3x8 FHCS to the side mount holes and tighten them down



Change the two front screws on the extruder one at a time, replace them with M3x30 SHCS

www.bondtech.se Page 2/5

Install an EBB36 mount on Voron Stealthburner





Take the EBB36 and add two M3x8 SHCS



Add the two spacers fitting your extruder variation and screw the EBB36 to the mount



Remove the lower nut from the PG7 and screw it into the mount



Add the EBB36 assembly to the extruder assembly



Add 2x M3x8 FHCS to the side mount holes and tighten them down



Change the two front screws on the extruder one at a time, replace them with M3x30 SHCS



Add the EBB36 assembly to the extruder assembly

www.bondtech.se Page 3/5



IT'S DONE! TAKE GOOD CARE OF IT

Toolhead boards can be quite a journey to install and get working, especially when you're unfamiliar with setting up CAN networks in Klipper, which honestly very few are.

For great aid in setting these up, we recommend the channel #can_bus_depot on the Voron Discord. There are many knowledgeable people there as well as great guides and resources in the channel pinned messages.



www.bondtech.se Page 4/5

